

EX-6100x Series Serial Server WEB User Manual

EX-61001v2 • EX-61002 • EX-61011



Table of Contents

Table of Contents	2
Preface	5
Target Audience	5
Conventions	5
1 Overview	6
1.1 Product Introduction	6
1.2 Product Features	6
2 Hardware Description	7
2.1 Power Interface Definition	7
2.2 Serial Port Pin Definition	7
2.3 Ethernet Port Pin Definition	8
3 Web Page	9
3.1 Web Page Login	9
3.3 Web Page Description	10
4 Basic Settings	11
4.1 Server Settings	11
4.2 Serial Port Settings	12
4.3 Mode Settings	13
4.3.1 VCOM Mode	13
4.3.2 TCP Server Mode	14
4.3.3 TCP Client Mode	15
4.3.4 UDP Client Mode	18
4.3.5 Modbus Server Mode	19
4.3.6 Modbus Client Mode	20

4.3.7 MCP Mode	21
4.4 System Status.....	22
4.5 System Management.....	23
4.6 Security Settings.....	24
4.7 User Settings	24
4.8 Save Settings	25
5 Troubleshooting	26
6 Vcom Software Description.....	29
6.1 Remote Devices Management	29
6.1.1 Device Search	29
6.1.2 Delete Serial Device Information	31
6.1.3 Login to Device	31
6.1.4 Configuration Information.....	32
6.1.5 Change IP	36
6.1.6 Logout	36
6.1.7 Import Configuration	37
6.1.8 Export Configuration	38
6.1.9 File Upgrade	39
6.1.10 Jump to Web Login	40
6.2 COM Mapping	40
6.2.1 Create Virtual Serial Port	40
6.2.2 Delete Virtual Serial Port	42
6.2.3 Modify Virtual Serial Port	42
6.2.4 Enable Virtual Serial Port	43
6.2.5 Disable Virtual Serial Port	43
6.2.6 Import Virtual Serial Port List	43

6.2.7 Export Virtual Serial Port List	45
6.3 Options	46
6.4 About	46
6.5 Exit	48
6.6 Language	48

Preface

Target Audience

This manual is intended for installation personnel and system administrators responsible for installing, configuring, or maintaining networks. This manual assumes that you are familiar with all the transmission and management protocols used in networks.

This manual also assumes that you are familiar with the professional terminology, theoretical principles, practical skills, and specific expertise related to networking equipment, protocols, and interfaces. Additionally, you should have experience working with graphical user interfaces, command-line interfaces, Simple Network Management Protocol (SNMP), and web browsers.

Conventions

This manual uses the following conventions.

GUI Conventions	Description
 Note	Descriptions of operations, providing necessary supplementary information.
 Warning	Reminders of precautions during operations, as improper operations may lead to data loss or device damage.

1 Overview

1.1 Product Introduction

The EX-61002 series is a serial server that provides 2 RS-232/485/422 serial ports and 1 10/100Base-T(x) network interface, enabling easy and convenient centralized management of dispersed serial devices and hosts over a network. This series of devices can achieve bidirectional transparent data transmission between RS-232/422/485 interfaces and Ethernet interfaces, allowing serial devices to immediately gain networking capabilities.


1.2 Product Features

- Supports 2 RS-232/485/422 serial ports for remote control functionality.
- Supports 1 10/100Base-T(x) Ethernet interface.
- Supports reset button to restore factory settings.
- Supports custom baud rates.
- Supports MCP and VCOM virtual serial ports.
- Supports ARP, IP, ICMP, UDP, TCP, HTTP, DHCP, MODBUS, and other protocols.
- Supports $\pm 4\text{KV}$ electrostatic protection for serial ports and 1.5KVAC isolation protection for Ethernet ports.
- Supports a wide operating temperature range of -40°C to 85°C .
- Supports DC 12V to 48V operating voltage.


2 Hardware Description

2.1 Power Interface Definition

This series of devices provides DC and 3-pin 5.08 power terminal power input on the front panel, with a power input range of 12-48VDC. It is recommended to use a power adapter with a DC plug specification of 2.5mm inner diameter and 5.5mm outer diameter.




DC



Terminal	Power Interface
1	Power Positive V+
2	Ground (GND)
3	Power Negative V-

2.2 Serial Port Pin Definition


RJ45	RS-232	RS-485	RS-422
1	TXD	A(+)	TXD+
2	RXD	B(-)	TXD-
3			RXD+
4			RXD-
5			
6	GND	GND	GND
7			
8			



2.3 Ethernet Port Pin Definition

The 10/100BaseT(X) Ethernet interface is located on the front panel of the device, with an RJ45 interface type. The port rate is adaptive but can also be fixed. The pin definition is as follows:


RJ45	EIA/TIA 568B	Definition
1	Orange/White	TX+
2	Orange	TX-
3	Green/White	RX+
4	Blue	Data+
5	Blue/White	Data-
6	Green	RX-
7	Brown/White	Data+
8	Brown	Data-



3 Web Page

3.1 Web Page Login

Users can open a web browser and enter the default address of the serial server: `http://192.168.1.125`, then press Enter. A login window will appear as shown below, supporting Chinese and English language switching. Enter the default username: admin and password: admin. Click the <Login> button to view the serial server's system status information.

**Note:**

When logging into the serial server, the PC must be set to an IP address in the same subnet as the serial server.

3.3 Web Page Description

The web management menu mainly provides network settings, serial port settings, mode settings, system status, system management, security settings, user settings, and save settings. The details are shown in the table below.

Menu Item	Description
Server Settings	Device model display, IP address, subnet mask, DHCP settings
Serial Port Settings	Serial port type and basic parameter settings
Operation Mode Settings	Mode selection, including TCP Server/TCP Client/UDP Client/MCP/VCOM/Modbus Server/Modbus Client, default is TCP Server mode
System Status	TCP, UDP connection status, serial communication statistics display
System Management	View software version, hardware version, MAC address
	Restore factory settings
	Firmware Upgrade
Security Settings	IP segments within the filter range will not be able to access the server via WEB
User Settings	Logout from the web interface
	Change user password
Save Settings	Save and Reboot

4 Basic Settings

4.1 Server Settings

1.Panel Description

The panel display area intuitively displays the system information of the serial server. The interface is shown below:

The screenshot shows the EXS web interface. The top header includes the EXS logo and user information (admin, Logout). The left sidebar lists navigation options: Server Settings, Serial Port Settings, Operation Mode Settings, System Status, System Management, Security Settings, User Settings, and Save Settings. The main content area is titled 'Server Settings' and contains a 'Server Parameters' section. This section includes input fields for the following parameters:

- Server Name: EX-61002
- IP Address: 192.168.1.125
- MAC Addr: 30-c6-f7-a3-47-a3
- Subnet Mask: 255.255.255.0
- Gateway: 192.168.1.1
- DNS Server1: 0.0.0.0
- DNS Server2: 0.0.0.0
- Ethernet Port Rate: Auto Negotiation (dropdown menu)
- DHCP: Disabled (dropdown menu)

At the bottom of the form are 'Cancel' and 'Submit' buttons.

2.Keyword Description


Server Name	Device Model display
IP Address	Device IP address
MAC Addr	MAC Address display
Subnet Mask	Device subnet mask
Gateway	Device gateway address
DNS Server1	Primary DNS address
DNS Server2	Secondary DNS address

Ethernet Port Rate	Auto-negotiation, 10M half-duplex/full-duplex, 100M half-duplex/full-duplex
DHCP	Whether to enable DHCP to obtain an IP address, default is disable

4.2 Serial Port Settings

1.Panel Description

This interface allows users to set the communication parameters for different serial ports on the serial server. The interface is shown below:



2.Keyword Description

Serial Port	Select Serial Port 1 or Serial Port 2
Interface	Serial port interface type selection, RS485/RS422
Baud Rate	Serial port baud rate, 300~921600, or select custom, default is 9600
Data Bits	Data bits, selectable 5/6/7/8
Parity Bit	Stop bits, selectable 1/1.5/2
Stop Bit	Parity bit, selectable Odd/Even, default is none

Flow Control	Flow control, selectable None, RTS/CTS
Interval Time	Data packing interval time, the delay time within the packing rule.
Packing Length	Data packing length. If the serial port receives a data frame smaller than this setting, it will wait for the interval time to see if more data follows.

4.3 Mode Settings

4.3.1 VCOM Mode

1.Panel Description

TCP/IP virtual serial port mode works in the Windows system environment. Through the driver, the port on the serial server is mapped to a virtual COM port on the local host, allowing upper-layer software originally based on COM port operations to work without any modifications, just like using a local real COM port. The driver can support up to COM256. Each independent port can support multiple sessions, making monitoring of serial devices more flexible and convenient. Multiple connection resources can also be used for connection backup. The interface is shown below:

The screenshot displays the EXSYS Serial Server WEB User Interface. The top header includes the EXSYS logo and a user login area showing 'admin' and a 'Logout' link. A left sidebar contains a navigation menu with the following items: 'Server Settings', 'Serial Port Settings', 'Operation Mode Settings' (which is highlighted), 'System Status', 'System Management', 'Security Settings', 'User Settings', and 'Save Settings'. The main content area is titled 'Operation Mode Settings' and contains two sections: 'Serial Port' and 'Operation mode Parameters'. In the 'Serial Port' section, there are radio buttons for '1' (selected) and '2'. The 'Operation mode Parameters' section includes four input fields: 'Connect Mode' (a dropdown menu set to 'VCOM'), 'Keep Alive' (a text input with '60' and a range '(30-600s)' to its right), 'Data Port' (a text input with '966'), and 'Command Port' (a text input with '967'). At the bottom of this section are two buttons: 'Cancel' and 'Submit'.

2.Keyword Description

Serial Port	Select Serial Port 1 or Serial Port 2
-------------	---------------------------------------

Connect Mode	Select connect mode: VCOM
Keep Alive	After the connection is established, the device will send keep-alive probe packets at this set interval to detect if the connection is still active
Data Port	Cannot be modified, use default
Command Port	Cannot be modified, use default

4.3.2 TCP Server Mode

1.Panel Description

In TCP server mode, the serial server is assigned an IP port number and passively waits for host connections. When a host initiates a connection request and establishes a connection with the serial server, the host can achieve bidirectional transparent data transmission with the serial port over the network. TCP server mode supports up to 6 simultaneous session connections, allowing multiple hosts to read or send Ethernet data to a single serial device. The interface is shown below:

The screenshot displays the EXSYS web interface. On the left is a sidebar with navigation links: Server Settings, Serial Port Settings, Operation Mode Settings (highlighted), System Status, System Management, Security Settings, User Settings, and Save Settings. The main content area is titled 'Operation Mode Settings'. It features a 'Serial Port' section with radio buttons for '1' (selected) and '2'. Below this is the 'Operation mode Parameters' section, which contains the following fields:

- Connect Mode: A dropdown menu currently showing 'DataSocket'.
- Connect Type: A dropdown menu currently showing 'TCP Server Mode'.
- Connect Num: A text input field with the value '2' and a range indicator '(1-6)'.
- Local Port: A text input field with the value '10000' and a range indicator '(0-65534)'.
- Keep Alive: A text input field with the value '60' and a range indicator '(30-600s)'.

At the bottom of the configuration area are two buttons: 'Cancel' and 'Submit'.

2.Keyword Description

Serial Port	Select Serial Port 1 or Serial Port 2
Connect Mode	Select connect mode: DataSocket
Connect Type	Select TCP Server Mode
Connect Num	Maximum number of client connections, 1-6
Local Port	TCP Listening port number, default is 10000
Keep Alive	After the connection is established, the device will send keep-alive probe packets at this set interval to detect if the connection is still active

4.3.3 TCP Client Mode

1.Panel Description

In TCP client mode, the serial server can actively establish a network connection with a user-specified host when serial data arrives. After data transmission is complete, the serial server will automatically close the network connection based on parameters such as keep-alive time/idle timeout time. Similarly, TCP client mode supports up to 6 simultaneous session connections, allowing multiple hosts to read or send Ethernet data to a single serial device. The interface is shown below:

Operation Mode Settings

Serial Port

Serial Port: ☒ 1 ☐ 2

Operation mode Parameters

Connect Mode: DataSocket

Connect Type: TCP Client Mode

Connect Num: 1 (1-6)

Keep Alive: 60 (30-600s)

Heartbeat Enable: Heartbeat Disable

Register Type: Register Package Disable

Remote IP: 0.0.0.0

Remote Port: 10000 (0-65534)

Local Port (If 0, the system automatically allocates): 10000 (0-65534)

Heartbeat and Registration function:

Heartbeat Enable: Network Heartbeat Packet

Heartbeat Time: 30 (1-65535s)

Heartbeat Encoding: ASCII

Heartbeat Content:

Register Type: Custom Register Package

Register Location: Connect To Send

Registration Encoding: ASCII

Register Content:

2.Keyword Description

Serial Port	Select Serial Port 1 or Serial Port 2
Connect Mode	Select connect mode: DataSocket
Connect Type	Select TCP Client Mode
Connect Num	Maximum number of client connections, 1-6
Additionl Protocol	None or RFC 2217,default is None
Keep Alive	After the connection is established, the device will send keep-alive probe packets at this set interval to detect if the connection is still

	active
Heartbeat Enable	Heartbeat Disabled:Disabled Network heartbeat packet: periodically send heartbeat packet content to the server
Heartbeat Time	Heartbeat packet sending interval, 1-65535s
Heartbeat Encoding	Encoding format: Ascii or Hex
Heartbeat Content	Custom heartbeat packet content
Register Type	Registration Packet Disable: disable MAC Registration Packet: send MAC address to the server Custom Registration Packet: send custom registration packet to the server
Register Location	Connect To Send:send when establishing a connection with the server Data Portablility:attach registration packet data to the front of each data packet Full Register:includes both of the above situations
Registration Encoding	Encoding format: Ascii or Hex
Registration Content	Custom registration packet content.
Remote IP/Port	Set the IP address and port number of the target host

4.3.4 UDP Client Mode

1.Panel Description

In UDP Client mode, the interface is shown below:

The screenshot shows the EXSYS web interface for the 'Operation Mode Settings' page. The left sidebar contains a navigation menu with the following items: Server Settings, Serial Port Settings, Operation Mode Settings (highlighted), System Status, System Management, Security Settings, User Settings, and Save Settings. The main content area is titled 'Operation Mode Settings' and includes a 'Serial Port' section with radio buttons for '1' (selected) and '2'. Below this is the 'Operation mode Parameters' section, which contains the following fields:

- Connect Mode: DataSocket (dropdown)
- Connect Type: UDP Client Mode (dropdown)
- Connect Num: 1 (text input, with a '(1-6)' hint)
- Remote IP/Port table with 6 rows (Remote IP1 to Remote IP6). Each row has three input fields: Remote IP (all set to 0.0.0.0), Remote Port (all set to 10000 to 10005), and Local Port (all set to 10000 to 10005). Each port input field has a '(0-65534)' hint.

At the bottom of the form are 'Cancel' and 'Submit' buttons.

2.Keyword Description

Serial Port	Select Serial Port 1 or Serial Port 2
Connect Mode	Select connect mode: DataSocket
Connect Type	Select UDP Client Mode
Connect Num	Maximum number of client connections, 1-6
Additionl Protocol	None or RFC 2217,default is None
Remote IP/Port	Set the IP address and port number of the target host

4.3.5 Modbus Server Mode

1.Panel Description

The device is set as a Modbus server, acting as a slave to respond to transaction requests. The interface is shown below:

The screenshot shows the EXSYS web interface for the 'Operation Mode Settings' page. The left sidebar contains a menu with the following items: 'Server Settings', 'Serial Port Settings', 'Operation Mode Settings' (which is highlighted), 'System Status', 'System Management', 'Security Settings', 'User Settings', and 'Save Settings'. The main content area is titled 'Operation Mode Settings' and contains two sections: 'Serial Port' and 'Operation mode Parameters'. In the 'Serial Port' section, there are two radio buttons for 'Serial Port': '1' (which is selected) and '2'. In the 'Operation mode Parameters' section, there are five input fields: 'Connect Mode' (a dropdown menu set to 'Modbus'), 'Connect Type' (a dropdown menu set to 'TCP Server Mode'), 'Connect Num' (a text input set to '1' with a range of '(1-6)' to its right), 'Local Port' (a text input set to '10000' with a range of '(0-65534)' to its right), and 'Keep Alive' (a text input set to '60' with a range of '(30-600s)' to its right). At the bottom of the form are two buttons: 'Cancel' and 'Submit'.

2.Keyword Description

Serial Port	Select Serial Port 1 or Serial Port 2
Connect Mode	Select connect mode: Modbus
Connect Type	Select TCP Server Mode
Local Port	Listening port number, default is 10000
Connect Num	Support 1 only
Keep Alive	After the connection is established, the device will send keep-alive probe packets at this set interval to detect if the connection is still active

4.3.6 Modbus Client Mode

1.Panel Description

The device is set as a Modbus client, acting as a master to initiate transaction requests. The interface is shown below:

The screenshot shows the EXSYS web interface for the 'Operation Mode Settings' page. The left sidebar contains a navigation menu with the following items: Server Settings, Serial Port Settings, Operation Mode Settings (highlighted), System Status, System Management, Security Settings, User Settings, and Save Settings. The main content area is titled 'Operation Mode Settings' and includes a 'Serial Port' section with radio buttons for '1' (selected) and '2'. Below this is the 'Operation mode Parameters' section, which contains the following fields:

- Connect Mode:** A dropdown menu set to 'Modbus'.
- Connect Type:** A dropdown menu set to 'TCP Client Mode'.
- Connect Num:** A text input field set to '1' with a '(1-6)' range indicator.
- Remote IP:** A table with 6 rows (Remote IP1 to Remote IP6) and 2 columns. Each row has a text input field set to '0.0.0.0'.
- Remote Port:** A table with 6 rows and 2 columns. Each row has a text input field set to a port number (10000 to 10005) and a range indicator '(0-65534)'.
- Local Port (If 0, the system automatically allocates):** A table with 6 rows and 2 columns. Each row has a text input field set to a port number (10000 to 10005) and a range indicator '(0-65534)'.

At the bottom of the 'Operation mode Parameters' section, there are 'Cancel' and 'Submit' buttons.

2.Keyword Description

Serial Port	Select Serial Port 1 or Serial Port 2
Connect Mode	Select connect mode: Modbus
Connect Type	Select TCP Client Mode
Connect Num	1-6
Remote Address/Port	Sets the IP address and port number of the target host to connect to.

4.3.7 MCP Mode

1.Panel Description

TCP/IP virtual serial port mode works in a Windows system environment. Through the driver, the ports on the serial server are mapped to virtual COM ports on the local host, allowing upper-layer software originally based on COM ports to operate without any modifications, just like using a local real COM port. The driver can support up to COM256. Each independent port can support multiple sessions, making monitoring of serial devices more flexible and convenient. Multiple connection resources can also be used for connection backup. The interface is shown below:

The screenshot displays the EXSIS web interface for configuring the serial server. The left sidebar lists various settings categories, with 'Operation Mode Settings' currently selected. The main panel shows the 'Operation Mode Settings' configuration. Under the 'Serial Port' section, '1' is selected via a radio button. The 'Operation mode Parameters' section includes a 'Connect Mode' dropdown set to 'MCP', a 'Keep Alive' input field set to '60' (with a range of 30-600s), a 'Data Port' input field set to '950', and a 'Command Port' input field set to '966'. 'Cancel' and 'Submit' buttons are located at the bottom of the configuration area.

2.Keyword Description

Serial Port	Select Serial Port 1 or Serial Port 2
Connect Mode	Select connect mode: MCP
Keep Alive	After the connection is established, the device will send keep-alive probe packets at this set interval to detect if the connection is still active
Data Port	Cannot be modified, use default
Command Port	Cannot be modified, use default

4.4 System Status

1.Panel Description

TCP Status

Displays the current system TCP connection status.


The screenshot shows the EXSYS web interface. On the left is a sidebar menu with options: Server Settings, Serial Port Settings, Operation Mode Settings, System Status (highlighted), System Management, Security Settings, User Settings, and Save Settings. The main content area is titled 'System Status' and contains a 'Device Status Display' section. Below this, there is a 'Status:' label followed by a dropdown menu currently set to 'TCP Status'. Below the dropdown is a table with the following headers: Type, Local IP, Remote IP, Local Port, Remote Port, Snd_nxt, Rcv_nxt, and Status. The table body is empty, displaying 'No Data'.

UDP Status

Displays the current system UDP connection status.

The screenshot shows the EXSYS web interface with the same sidebar menu. In the main content area, the 'System Status' section has the 'Device Status Display' dropdown set to 'UDP Status'. Below the dropdown is a table with the following headers: Local IP, Remote IP, Local Port, and Remote Port. The table body is empty, displaying 'No Data'.


Serial Status



Ser	Total RX	Total Tx	RTS	CTS	DTR	DSR
1	0	0	OFF	OFF	OFF	OFF
2	1	0	OFF	OFF	OFF	OFF

4.5 System Management

1.Panel Description



2.Keyword Description

Firmware Version	Displays the current device's firmware version number
Hardware Version	Displays the current device's hardware version number
Load Factory Default	Restore factory settings
Upgrade Firmware	Software upgrade

4.6 Security Settings

1.Panel Description

IP filter settings, IP segments within the filter range will not be able to access the server via WEB. The interface is shown below:

The screenshot shows the EXSYS web interface for Security Settings. The left sidebar contains a menu with options: Server Settings, Serial Port Settings, Operation Mode Settings, System Status, System Management, Security Settings (highlighted), User Settings, and Save Settings. The main content area is titled 'Security Settings' and contains a sub-section 'IP Filter Settings'. It displays a table with four rules, each with input fields for 'Start IP Address' and 'End IP Address', and a 'Status' column. All rules are currently 'Disabled'. At the bottom of the table are 'Cancel' and 'Submit' buttons.

	Start IP Address	End IP Address	Status
Rule 1:	0.0.0.0	0.0.0.0	Disabled
Rule 2:	0.0.0.0	0.0.0.0	Disabled
Rule 3:	0.0.0.0	0.0.0.0	Disabled
Rule 4:	0.0.0.0	0.0.0.0	Disabled

Cancel Submit

4.7 User Settings

1.Panel Description

The screenshot shows the EXSYS web interface for User Settings. The left sidebar is the same as in the previous screenshot, with 'User Settings' highlighted. The main content area is titled 'User Settings' and contains a 'Logout' button and a 'Change Password' section. The 'Change Password' section has three input fields: 'Original Password:', 'New Password:', and 'Confirm Password:'. At the bottom are 'Cancel' and 'Submit' buttons.

Logout

Change Password

Original Password:

New Password:

Confirm Password:

Cancel Submit


2.Keyword Description

Change Password	Enter the original password and new password to change the user password.
-----------------	---

4.8 Save Settings

1.Panel Description

Click reboot to apply the configuration.



5 Troubleshooting

a) Running search does not find the serial server's IP address

1. First, check if the physical connection is normal, if the network cable (distinguish between crossover and straight-through cables) and power are connected, and observe the power indicator, LAN light, and ACT light (this light does not light up when connected to a 10M network, only when connected to a 100M network).
2. Check if the host's network card is available and if it can communicate with other local hosts.
3. Close all tools and software that can block broadcast packets (do not enable the system's built-in firewall).
4. If the IP address is suddenly lost during configuration through the browser (e.g., due to a power outage), use the console port to reconfigure the IP.

b) Unable to open the serial port

1. Ensure that the network is working normally and that the server can be pinged.
2. Check the working status to see if the port is occupied.
3. If using VCOM mode, check if the "VCOM Utility" configuration is correct.
4. Delete the corresponding COM port from the registry and remap it.

c) Unable to send or receive data

1. Ensure that the serial port can be opened normally.
2. Observe if the system light is flashing quickly or slowly. A fast flash indicates data transmission. If there is no fast flash, check the connection between the serial port and the upper network, and check the wiring of the lower serial port device.

d) Forgot the previously set password

1. Restore factory settings by holding the "reset" button for 5 seconds.

e) Data sent or received is garbled

1. Check if the wiring is correct. Our 485 wiring is 1A+, 2B-.
2. Check if the line distance exceeds the standard distance and the quality of the line (you can also use a line extender or optical isolator).
3. Check if the baud rate setting matches the lower device.
4. Disconnect from the customer's upper software and use a network or serial port debugging tool to see if normal data can be received. If normal data can be received, the issue may be related to the packing mechanism. You can set the packing length and packing wait time in "Port Configure".

f) When the serial communication server is used as a dial-up server, the connection is established normally, but the client PC cannot open the webpage when entering the domain name in the address bar; however, it can open the webpage when entering the IP address in the address bar

1. Check if the DNS set in the serial communication server is valid.

g) When the serial communication server is used as a dial-up server, the connection is established normally, but the client PC often fails to open complex webpages or download large files completely, or even fails

1. Check the [Serial Port] settings in the serial communication server to ensure that the [Flow

Control] matches the MODEM's flow control. Typically, the MODEM's flow control is RTS/CTS (hardware flow control).

2. The DCE rate negotiated between MODEMs is too low. Redial.

h) Cannot be connected as a TCP server

1. Confirm that no other PC is connected to the corresponding port of the serial communication server: check [Active TCP Information] in the [Statistics] of the serial communication server.

2. Check if [Authentication] in [Detailed Parameters] is set to [none].

If the above methods do not resolve your issue, please contact the manufacturer.

6 Vcom Software Description

6.1 Remote Devices Management

6.1.1 Device Search

After connecting the device, start the "VCOM" software (as shown in Figure 1), select Remote Devices Management---Add Device, and a search interface for finding the IP address of the device in the network will pop up; as shown in Figure 2, click the "Search" button to search for the IP addresses and basic information of all devices in the network; as shown in Figure 3, then click "Cancel" in Figure 3 and "OK" in Figure 2, and the device information found will be displayed in the VCOM interface, as shown in Figure 4:




Figure 1




Figure 2




Figure 3





Figure 4

6.1.2 Delete Serial Device Information

In the "VCOM" software, first select the device information, then click "Remove Device" in the Remote Devices Management interface to delete the device information, as shown below:



6.1.3 Login to Device

In the "VCOM" software, click the "Login" button in the Remote Devices Management interface, and a pop-up window will appear as shown in Figure 1. Enter the login password to complete the login; after successful login, it will display as shown in Figure 2.




Figure 1





Figure 2

6.1.4 Configuration Information

After logging into the device, click the "Setting" button to bring up the interface as shown below.


6.1.4.1 Basic

Displays basic device information. Keep the default state as shown below.



6.1.4.2 Network

Used for IP-related configuration, consistent with the serial server configuration.



6.1.4.3 Serial

Used for basic information configuration of the ports, as shown in Figure 1. Double-click the corresponding item in the "Settings" of the selected serial port or select the corresponding serial port and click the "Configure" button to open the configuration interface, as shown in Figure 2.




Figure 1





Figure 2


6.1.4.4 SNMP

Used to enable SNMP management function, consistent with the serial server configuration.




6.1.4.5 Change Password

Used to modify the user password of the serial server, consistent with the serial server configuration.




6.1.5 Change IP

In the "VCOM" software, click the "Assign IP" button in the Remote Devices Management interface, and a pop-up window will appear as shown below. You can reset the IP address of the serial server (you need to log in before changing the IP).



6.1.6 Logout

In the "VCOM" software, click the "Logout" button in the Remote Devices Management interface, and a pop-up window will appear as shown below, indicating successful logout.



6.1.7 Import Configuration

In the "VCOM" software, after successfully logging into the device, click the "Import Settings" button in the Remote Devices Management interface, and a pop-up window will appear as shown in Figure 1; then click "Browse" to select the saved or exported configuration file, as shown in Figure 2, and click "OK" to bring up the interface as shown in Figure 3; click "OK" and wait for the configuration to be successfully imported.




Figure 1




Figure 2




Figure 3

6.1.8 Export Configuration

In the "VCOM" software, after successfully logging into the device, click the "Export Settings" button in the Remote Devices Management interface, and a pop-up window will appear as shown in Figure 1; then click "Browse" to select the saved or exported configuration file, as shown in Figure 2, and click "OK" to wait for the configuration to be successfully exported; as shown in Figure 3.




Figure 1




Figure 2





Figure 3

6.1.9 File Upgrade

In the "VCOM" software, after successfully logging into the device, click the "Firmware Update" button in the Remote Devices Management interface, and a pop-up window will appear as shown below. Click "Browse" to select the update file, click "OK", wait for 240 seconds, and the upgrade will be completed.



6.1.10 Jump to Web Login

In the "VCOM" software, click the "Open in Browser" button in the Remote Devices Management interface to enter the web login interface through the IE browser.

User Login

Please enter a username


Please enter a password

Login


6.2 COM Mapping

6.2.1 Create Virtual Serial Port

1. In the "VCOM" software, select COM Mapping---Add COM, and the "Add Device" window will pop up, as shown below.



2. The "Add Device" window will appear. Select the device and click "OK".




3. The interface shown below will pop up, indicating that the corresponding virtual serial port has been created.

The screenshot shows the VCOM Remote Device Management interface with the 'COM Mapping' tab selected. The 'Add COM' button is highlighted. The main table displays the completed COM mapping for 32 devices, each with 32 ports, all having the IP 172.16.14.141. The 'Port' column ranges from 1 to 32, and the 'COM Port' column ranges from COM18 to COM52. The 'Connection Status' column shows 'N/A' for all entries.

#	Type	IP	Port	COM Port	Connection Status
1	32 ports	172.16.14.141	1	COM18	N/A
2	32 ports	172.16.14.141	2	COM20	N/A
3	32 ports	172.16.14.141	3	COM21	N/A
4	32 ports	172.16.14.141	4	COM22	N/A
5	32 ports	172.16.14.141	5	COM23	N/A
6	32 ports	172.16.14.141	6	COM24	N/A
7	32 ports	172.16.14.141	7	COM25	N/A
8	32 ports	172.16.14.141	8	COM26	N/A
9	32 ports	172.16.14.141	9	COM29	N/A
10	32 ports	172.16.14.141	10	COM30	N/A
11	32 ports	172.16.14.141	11	COM31	N/A
12	32 ports	172.16.14.141	12	COM32	N/A
13	32 ports	172.16.14.141	13	COM33	N/A
14	32 ports	172.16.14.141	14	COM34	N/A
15	32 ports	172.16.14.141	15	COM35	N/A
16	32 ports	172.16.14.141	16	COM36	N/A
17	32 ports	172.16.14.141	17	COM37	N/A
18	32 ports	172.16.14.141	18	COM38	N/A
19	32 ports	172.16.14.141	19	COM39	N/A
20	32 ports	172.16.14.141	20	COM40	N/A
21	32 ports	172.16.14.141	21	COM41	N/A
22	32 ports	172.16.14.141	22	COM42	N/A
23	32 ports	172.16.14.141	23	COM43	N/A
24	32 ports	172.16.14.141	24	COM44	N/A
25	32 ports	172.16.14.141	25	COM45	N/A
26	32 ports	172.16.14.141	26	COM46	N/A
27	32 ports	172.16.14.141	27	COM47	N/A
28	32 ports	172.16.14.141	28	COM48	N/A
29	32 ports	172.16.14.141	29	COM49	N/A
30	32 ports	172.16.14.141	30	COM50	N/A
31	32 ports	172.16.14.141	31	COM51	N/A
32	32 ports	172.16.14.141	32	COM52	N/A

6.2.2 Delete Virtual Serial Port

In the "VCOM" software, first select the virtual serial port to be deleted, then click "Remove COM" in the COM Mapping interface to delete the virtual serial port, as shown below.



6.2.3 Modify Virtual Serial Port

In the "VCOM" software, first select the virtual serial port to be modified, then click "Modify COM" in the COM Mapping interface, and the interface shown in Figure 1 will pop up. Then select "COM60" to modify Port1 from "COM18" to "COM60", as shown in Figure 2.




Figure 1





Figure 2


6.2.4 Enable Virtual Serial Port

In the "VCOM" software, first select the virtual serial port to be enabled, then click "Enable COM" in the COM Mapping interface to enable the corresponding virtual serial port, as shown below.



6.2.5 Disable Virtual Serial Port

In the "VCOM" software, first select the virtual serial port to be disabled, then click "Disable COM" in the COM Mapping interface to disable the corresponding virtual serial port, as shown below.



6.2.6 Import Virtual Serial Port List

In the "VCOM" software, click "Import COM List" in the COM Mapping interface, and the interface shown in Figure 1 will pop up. Click "Browse" and select the saved virtual serial port configuration information, as shown in Figure 2, then click "OK" to successfully import, as shown in Figure 3.




Figure 1




Figure 2

VCOM

Remote Device Management | COM Mapping | Options | About | Exit | Language

Add COM Input COM Remove COM Modify COM Enable COM Disable COM Import COM List Export COM List

# ^	Type	IP	Port	COM Port	Connection Status
1	32 ports	172.16.14.141	1	COM18	N/A
2	32 ports	172.16.14.141	2	COM20	N/A
3	32 ports	172.16.14.141	3	COM21	N/A
4	32 ports	172.16.14.141	4	COM22	N/A
5	32 ports	172.16.14.141	5	COM23	N/A
6	32 ports	172.16.14.141	6	COM24	N/A
7	32 ports	172.16.14.141	7	COM25	N/A
8	32 ports	172.16.14.141	8	COM26	N/A
9	32 ports	172.16.14.141	9	COM29	N/A
10	32 ports	172.16.14.141	10	COM30	N/A
11	32 ports	172.16.14.141	11	COM31	N/A
12	32 ports	172.16.14.141	12	COM32	N/A
13	32 ports	172.16.14.141	13	COM33	N/A
14	32 ports	172.16.14.141	14	COM34	N/A
15	32 ports	172.16.14.141	15	COM35	N/A
16	32 ports	172.16.14.141	16	COM36	N/A
17	32 ports	172.16.14.141	17	COM37	N/A
18	32 ports	172.16.14.141	18	COM38	N/A
19	32 ports	172.16.14.141	19	COM39	N/A
20	32 ports	172.16.14.141	20	COM40	N/A
21	32 ports	172.16.14.141	21	COM41	N/A
22	32 ports	172.16.14.141	22	COM42	N/A
23	32 ports	172.16.14.141	23	COM43	N/A
24	32 ports	172.16.14.141	24	COM44	N/A
25	32 ports	172.16.14.141	25	COM45	N/A
26	32 ports	172.16.14.141	26	COM46	N/A
27	32 ports	172.16.14.141	27	COM47	N/A
28	32 ports	172.16.14.141	28	COM48	N/A
29	32 ports	172.16.14.141	29	COM49	N/A
30	32 ports	172.16.14.141	30	COM50	N/A
31	32 ports	172.16.14.141	31	COM51	N/A
32	32 ports	172.16.14.141	32	COM52	N/A

Figure 3

6.2.7 Export Virtual Serial Port List

In the "VCOM" software, click "Export COM List" in the COM Mapping interface, and the interface shown in Figure 1 will pop up. Click "Browse" and select the path to save the virtual serial port configuration information, as shown in Figure 2, then click "OK" to successfully export, as shown in Figure 3.




Figure 1




Figure 2





Figure 3


6.3 Options

When starting the VCOM software, you can choose whether to open it directly or minimize it to the taskbar. By default, the software is minimized to the taskbar. The configuration is shown below.



6.4 About

Click the "About" button to view the software version information, as shown below.



6.5 Exit

Click the "Exit" button to exit the software.

6.6 Language

Switch the language, you can choose Chinese or English.

